#### BASIC COMPUTER USAGE

# Windows Installation

# Things you need to know before setup OS



#### Understanding Windows 10 Editions

Windows 10 Home, Enterprise, Professional



#### **Understanding Windows Licenses**

How to buy license, license pricing, checking license



#### System Requirement for Windows 10

RAM, Hard disk space, CPU,...



#### Get to know Administrator User

Managing user, Administrator, Root



# **Understanding Windows 10 Editions**

Commonly, there are *5 editions* of Windows 10:



Windows 10
Home

Designed for general users primarily accessing Windows at Home



Windows 10 Pro

A solid foundation for every business



Designed for people with advanced workloads or data needs.



The foundation for businesses and enterprises who need security, reliability and management controls



For organizations with advanced security and management needs



## **Understanding Windows Licenses**

Microsoft Windows has two different type of License


- Windows Client License
- Windows Server License

#### **Windows Client License**

There are three type of Windows Client Licenses:

- Retail License
- OEM License
- Volume License







### **Understanding Windows Licenses**



**Retail:** This license is called Full Packaged Product (FPP), commonly known as a "boxed copy" This license type has one license key (product key). You can use this key on another computer as long as you deactivate the old device.



**OEM (Original Equipment Manufacturer):** Provided by the system manufacturer. This license type cannot use it on another computer. Also, if this Windows version is Windows 8 or Windows 10, the license key is embedded in UEFI/BIOS firmware chip.



**Volume:** This type of license is an institutional license type, such as schools and government offices. These non-resale licenses provide common use. This means that Windows is activated on multiple computers with a single license key.



# **System Requirement for Windows 10**

System requirement for installing windows 10:

Processor:	1 gigahertz (GHz) or faster processor
RAM:	2GB for 32-bit OS or 4GB for 64-bit OS
Hard drive space:	20GB for 32-bit OS 32GB for 64-bit OS




#### **Get to know User Account**


There are two type of user account on Windows 10 including **Administrator and Standard user**. Each one offering different set of permission to device and applications.

- ✓ Administrator user has complete system control permission, which means that users can change settings globally, install apps, execute tasks, and perform pretty much anything.
- ✓ Standard user account type is more restrictive. Users with the standard account can work with apps, but they can't install new applications. They can change settings, but only those that won't affect other accounts.


# How to check account type



# How to check account type




# How to check account type



# **Understanding File System**

- ❖ In a computer, a **file system** (sometimes written *filesystem*) is the way in which files are named and where they are placed logically for storage and retrieval.
- ❖ There are many types of file system such as EXT2, EXT3, EXT4, FAT, NTFS....
- There are some file systems that Windows support natively:
  - FAT (out of date)
  - FAT32
  - exFAT
  - NTFS



# **Understand how to install Windows on a Computer**

#### Materials needed for setup new OS on a laptop/desktop:

- Bootable media (USB Flash, CD, DVD...)
- Laptop/desktop

#### **Step to setup new OS on computer:**

- 1. Connect bootable media to computer
- 2. Change boot option on computer to boot from bootable media instead of HDD
- 3. After that start to install a new OS to computer hard disk drive




#### **Introduction to Device Driver**

- After OS installation is completed, there can still be devices not working. Sometimes you
  cannot access the network, print documents, do your daily tasks and work for your specific
  needs ...
- If you want your computer run smoothly and be useful for you, you need to check driver on your computer.








#### **The Meaning of Driver**


- Drivers are software that enable one or more hardware devices to communicate with the computer's Operating System.
- For Windows OS, many Drivers are already part of the OS, but some are still missing. You can see missing drivers in **Device Manager**




#### **Check Location of Driver**

**Device Manager** is a <u>Control Panel</u> in <u>Microsoft Windows</u> operating systems. It allows users to view and control the hardware attached to the computer.


Access Device Manager: RUN → devmgmt.msc





#### **Check Location of Driver**

All the driver display on device manager



# HOW TO INSTALL DEVICE DRIVERS?


#### **Method Driver Installation**

#### 1. Install driver by using update on device manager:

- In the Device Manager, click on the device you want to update.
- Right-click the device and click Properties.
- In the Properties window, click the **Driver** tab.
- Click the Update Driver button.

#### **Method Driver Installation**

Right click on device driver that you want to update



#### **Method Driver Installation**


#### 2. Install driver by download driver from manufacturer website


- ✓ Step 1: you need the model number for your laptop and type of OS
- ✓ Step 2: identify the hardware manufacturer and find their support website online
- ✓ Step 3: go to the hardware manufacturer's site and download section
- ✓ Step 4: search the download section for the correct driver that you need
- ✓ Step 5: download the needed driver

How to check serial number: RUN -> cmd -> wmic bios get serialnumber

#### How to make sure driver installed

 All the driver, if you're want to make sure that installed or not you can verify on the device manager. By run→ devmgmt.msc, and you check all the device and all components.








# What is windows update?

**Windows Update** is a Microsoft Service that's used to provide updates for the Windows operating system and other Microsoft software.

> Note: Windows Update does not update non-Microsoft software.



# Why need to update your windows?



#### **Updates are additions to software that can help to:**

- Prevent or fix problems
- Improve how your computer works
- Enhance your computing experience
- Updates often include feature enhancements and security updates to protect Windows from malware and malicious attacks.







# Update window using windows update

- How you access Windows Update depends on which Windows operating system you're using:
- Windows update is part of System Settings, available from the Start Menu

Click on Start button, and then go to Settings > Update & Security > Windows Update



# Update window using windows update

Windows Settings

Find a setting



#### System

Display, sound, notifications, power



#### Devices

Bluetooth, printers, mouse



#### Phone

Link your Android, iPhone



#### Network & Internet

Wi-Fi, airplane mode, VPN



#### Personalization

Background, lock screen, colors



#### ٩pps

Uninstall, defaults, optional features



#### Accounts

Your accounts, email, sync, work, other people



#### Time & Language

Speech, region, date



#### Gaming

Game bar, captures, broadcasting, Game Mode



#### Ease of Access

Narrator, magnifier, high contrast



#### Search

Find my files, permissions



#### Cortana

Cortana language, permissions, notifications



#### Privacy

Location, camera, microphone



#### Update & Security

Windows Update, recovery, backup



# **Update window using windows update**

